

**Activity tray (D416) and
Activity tray-table (D414)**

Suitably sized for
collaborative play.



Switch seamlessly
between sensory activities
and academic tasks.

Table top has a
latch that clips on.



To adjust the table height,
just push the yellow ring down
and slide the leg in or out



Tray lifts out for easy cleaning,
and fits through standard door frames
so you can get to the sink!



Height-adjustable and accessible for all.
Remove the legs for a floor tray option,
or compact storage.



Ready for desk work? Securing the
table top over your loose parts keeps
everything neat and tidy.




The table top fits neatly
into the Sand and water
storage shelf.

NEW Activity tray-tables

ECERS 1:7.2, 3:5.4, 34:7.2 ITERS 1:7.2, 3:5.3, 20:5.4

It looks like a classroom desk, but offers unparalleled functionality, including both sitting and standing collaborative play options. Children with SEND gain access to the complete curriculum, transitioning effortlessly between sensory play and desk-based activities. The sturdy table top clips on tightly, keeping loose parts contained. The inset tray is removable, giving more play options and an easy clean. This one-stop shop will accrue thousands of hours of inspired learning.

Trays are 4 cm deep.



**Activity floor tray
D411**
For ages 9–15 months



**Activity tray,
medium adjustable D413**
For ages 15 months–5 years



**Activity tray,
high adjustable D416**
For ages 3 years and over



**Activity floor tray-table
D412**
For ages 9–15 months



**Activity tray-table,
medium adjustable D414**
For ages 15 months–5 years



**Activity tray-table,
high adjustable D417**
For ages 3 years and over



**Sand and water storage shelf
A698**



Floor tray: 10 cm high.
For ages 9–15 months.



With medium adjustable legs: Height adjusts
from 43 to 63 cm. For ages 15 months–5 years.



With high adjustable legs: Height adjusts
from 56 to 79 cm. For ages 3 years and over.



This Activity tray-table is a multi-sensory curriculum resource that supports inclusion.

Accessories


Four adjustable legs A594
Choose medium or high



Activity tray-table top D418