

Kitchenette (C525)

Round handholds on each unit are perfect for posting.



Safe
Units latch securely into place – no tools needed.



Bamboo backs on Sink, Cooker, Washing machine, and Low cabinet give a natural, homely feel.



Magnetic whiteboards on Fridge and Welsh dresser encourage mark making.



Learning and development

Babies love the posting holes, mirrors, doors that open, and dials that turn.



Adjustable height

Low units are just the right height for toddlers. Stack them on drawers for older children.



Easy for Staff

Tool-free latches and convenient handholds make reconfiguring your home corner set simple.

Home corner furniture

ECERS 24:5.3, 5.4 ITERS 20:5.2, 5.4

Just like home. With dials and taps that turn, doors that open, raised burners, and the natural warmth of wood, our home corner furniture creates a child-size world of work and play. Modular to each other and to Roomscapes shelving, you can arrange the units in any way you choose. The drawer unit can be used to raise any home corner unit for older children. Slip a kitchen bowl into the sink unit to add water.

For ages 1–6



Cooker and drawer
C513



Low cooker
C503



Sink and drawer
C512



Low sink
C502



Fridge
C505
Includes deep tote and 4 magnets



Low cabinet
C501



Welsh dresser
C506
Includes shallow tote and 4 magnets



Washing machine
C504



Time for tea! Stacking stools make child-sized seating in the kitchen. See page 113.

Accessories



Extra set of 10 magnets
H540



Arch
C510
Use with 2 Welsh dressers



Drawer
C509



Pinch-free,
self-closing hinges.



Home corner sets

ECERS 24:5.3, 5.4 ITERS 20:5.2, 5.4

Home is where the heart is. This area holds a timeless charm that will enchant little home-bodies, and its significance cannot be overstated. It need not be a corner – create a shared space anywhere in your room where children can gather, share thoughts, express feelings, and belong.

Choose from our preconfigured sets for an easy way to start. These modular units allow for arranging, changing, and adding to your collection over time.



Create a kitchen island. Place three Home corner units against a D372 MultiTable to encourage collaboration and create opportunities for enriched language. For older children, extend the table legs and stack the Home corner units on drawers.



Complete home corner

C555

For ages 3–5.

Everything including the kitchen sink! Make your home corner the family hub, with a kitchen living room style layout. Enjoy puppet theatre entertainment and popcorn while the washing gets done on the side.



Country kitchen

C535

For ages 3–5.

The heart of the home is where everyone can pitch in and help out. Little ones search the cupboards for a favourite mug, load the washing machine, or defrost the veg while chatting and laughing about the day. It's the perfect place to share exciting announcements and spill secrets.





Sussex kitchen

C537

For ages 2–5. This popular combination of home corner favourites provides many role play opportunities. A shop on High street one day becomes a science laboratory the next, but there's always lots of work getting done. For older children, purchase two additional drawers to raise sink and cooker height.



Kitchenette

C525

For ages 2–5. Cook a five star meal in a mini-kitchen. The two drawer units in this compact kitchen make it adaptable for a wide range of children.



Toddler collection

C530

For ages 1–3. Create a space your toddlers love exploring, with turning dials, shiny mirrors and posting holes. Pinch-free and sturdy, this child-friendly area is a worry-free world of discovery.



Starter home corner

C538

For ages 1–3. Starting with the basic items allows room to grow your collection in the future. (Studio flats are eco-friendly, and you're less likely to forget to turn off the stove burner!)

Drama centre (C700)
and **Peg tree (H559)**



The peg tree collects hats, scarves and necklaces.

Hook spots hold the Flowie in place.

Compact dress-up unit (C715)



Done for the day, or just ready for a change of scenery? Flip up the trim, roll to a new location, and flip it down to lock in place.



The dress-up box is a cosy space to climb into, and even the youngest toddlers can help at clean-up time.

Drama centres

ECERS 24:5,4 ITERS 2:7,3, 5,3; 20:5,3

Role play, dramatic play, imaginative play – everyone agrees it's essential. It starts with a dress-up unit with lots of storage space. Click the arches into place, toss a Flowie over them, and you have an instant stage or cosy space. Made of transparent netting, the Flowie will give children a sense of being in their own world while you can still supervise.


The compact drama centre saves on space and serves younger children. Instead of trays for storage, we provided a dress-up box.

Accessories

-  **Flowie, Sage C707**
218 cm x 310 cm
-  **Flowie, Sky C708**
218 cm x 310 cm
-  **Flowie, Sand C709**
218 cm x 310 cm




Drama centre C700
Choose Flowie colour:   
Includes Dress-up unit, Arches kit and Flowie



Dress-up unit C705
Includes 3 deep clear trays and 3 shallow clear totes



Peg tree H559



Drama centre arches kit C706
Choose Flowie colour:   
Includes 2 arches and a Flowie



Compact drama centre C710
Choose Flowie colour:   
Includes Compact dress-up unit, Compact arches kit and Flowie



Compact dress-up unit C715



Theatre set C945
Choose colour:   
Includes Compact drama centre and Small corner stage set



Compact drama centre arches kit C716
Choose Flowie colour:   
Includes 2 arches and a Flowie



Child's rocker (J940)
The home corner can be busy, so give your children a place to relax.



Doll cradle (C140)
The cradle can comfortably hold a small child with a soft toy.



Doll bed (C110)
Stack up two to make a cosy bunk for sleepy dolls.

Pushcart (D120)



Carefully designed to resist tipping, the Pushcart is perfect for one-year-olds taking their first steps.



Doll furniture

ECERS 24:5.3 ITERS 20:7.2, 5.4

Doll furniture supports children's love of dramatic and social play. This open-ended equipment is solidly constructed and provides rich opportunities to re-enact the events of daily life.

For ages 2–6



Home corner set C138
Includes Pushcart, rocker, doll high chair and bed



Playsize set of three C145
Includes rocker, cradle and doll high chair



Pushcart D120



Doll cradle C140



Doll bed C110



Child's rocker J940



Doll high chair D130



Children can easily lift and carry the Doll high chair, using the side handholds.



Child's sofa
(J651)



Child's armchair
(J640)



Impermeable cushions can be cleaned with soap and water. Stains are easily removed.



Highly durable, puncture-resistant cushions allow for years of daily use.



An armchair creates an inviting space that provides quiet, security and the feel of home: time-out during a busy day.



Where would you go with a good book? The child's sofa adds a welcoming touch and invites curling up for a good read.

Child's sofa and armchair

ECERS 3:7.1

Perfect for the book corner and role play areas, this soft seating will bring a touch of home to your setting. Children love this furniture which is just their size. With a 39 cm seat depth, these seats are comfortable for adults too.

Upholstery is tough, waterproof and easily cleaned.



Child's sofa, beige
J650



Child's sofa, blue
J651



Child's armchair, beige
J640



Child's armchair, blue
J641



There's plenty of room on this sofa – and since it's sized perfectly for children, everyone gets a good view at story time.



Round Play table set (C233)

Clear, child-safe finish brings out the beauty of the solid wood.



The home-like touch
Smoothly rounded edges and solid 3 cm birch top.

Wobble-free solid hardwood legs at the outermost edge of the table make it exceptionally steady.



Round play table
53 cm high (C231)



Square play table
40 cm high (C221)



Rectangular play table
30 cm high (C241)

Play tables


ECERS 2:5.1, 5.2 ITERS 2:7.2, 5.2

As the centrepiece of the home corner, Play tables invite children in for a cup of tea or a royal banquet.


Order a table and chair set, or make your own using the age-appropriate chair and table heights on page 101 as a guide.

Because these tables have solid wood tops they are not recommended for real meals or wet/messy activities.

Solid wood leg height ranges



Square Play table C221
Includes 4 legs
Choose 30, 36, 40, 46 or 53 cm table height



Round Play table C231
Includes 4 legs
Choose 30, 36, 40, 46 or 53 cm table height



Rectangular Play table C241
Includes 4 legs
Choose 30, 36, 40, 46 or 53 cm table height



Square Play table set
Includes Table and 2 Woodcrest chairs
Table 53 cm and chairs 31 cm
C224
Table 46 cm and chairs 26 cm
C223
Table 40 cm and chairs 21 cm
C222



Round Play table set
Includes Table and 2 Woodcrest chairs
Table 53 cm and chairs 31 cm
C234
Table 46 cm and chairs 26 cm
C233
Table 40 cm and chairs 21 cm
C232



Rectangular Play table set
Includes Table and 4 Woodcrest chairs
Table 53 cm and chairs 31 cm
C244
Table 46 cm and chairs 26 cm
C243
Table 40 cm and chairs 21 cm
C242



See p.113 **Stacking stools**