

Kitchenette (C525)

Round handholds on each unit are perfect for posting.



Safe
Units latch securely into place – no tools needed.



Bamboo backs on Sink, Cooker, Washing Machine, and Low Cabinet give a natural, homely feel.



Magnetic whiteboards on Fridge and Welsh Dresser encourage mark making.



Learning and development

Babies love the posting holes, mirrors, doors that open, and dials that turn.



Adjustable height

Low units are just the right height for toddlers. Stack them on drawers for older children.



Easy for Staff

Tool-free latches and convenient handholds make reconfiguring your home corner set simple.

Home Corner Furniture

ECERS 24:5.3, 5.4 ITERS 20:5.2, 5.4

Just like home. With dials and taps that turn, doors that open, raised burners, and the natural warmth of wood, our home corner furniture creates a child-size world of work and play. Modular to each other and to Roomscapes shelving, you can arrange the units in any way you choose. The Drawer unit can be used to raise any home corner unit for older children. Slip a kitchen bowl into the Sink unit to add water.

For ages 1–6



Cooker and Drawer C513



Low Cooker C503



Sink and Drawer C512



Low Sink C502



Fridge C505
Includes Deep Tote and 4 Magnets



Low Cabinet C501



Welsh Dresser C506
Includes Shallow Tote and 4 Magnets



Washing Machine C504



Time for tea! Stacking Stools provide child-sized seating in the kitchen. See page 155.

Accessories



Extra set of 10 Magnets **H540**



Arch C510
Use with 2 Welsh Dressers



Drawer C509



Pinch-free,
self-closing hinges.



Home Corner Sets

ECERS 24:5.3, 5.4 ITERS 20:5.2, 5.4

Home is where the heart is. This area holds a timeless charm that will enchant little home-bodies, and its significance cannot be overstated. It need not be a corner – create a shared space anywhere in your room where children can gather, share thoughts, express feelings, and belong.

Choose from our preconfigured sets for an easy way to start. These modular units allow for arranging, changing, and adding to your collection over time.



Add stacking stools and a play table to your home corner to make a fashionable kitchen-cum-diner. Products shown are Complete home corner C555, Stacking stools J123, and Round play table C231.



Complete Home Corner

C555

For ages 3–5.

Everything including the kitchen sink! Make your home corner the family hub, with a kitchen living room style layout. Enjoy puppet theatre entertainment and popcorn while the washing gets done on the side.



Washing Machine
C504

Low Cooker
C503

Low Sink
C502

Low Cabinet
C501

Fridge
C505

2 Welsh Dressers
C506

Arch
C510

8 Drawers
C509



Country Kitchen

C535

For ages 3–5.

The heart of the home is where everyone can pitch in and help out. Little ones search the cupboards for a favourite mug, load the washing machine, or defrost the veg while chatting and laughing about the day. It's the perfect place to share exciting announcements and spill secrets.



Low Sink
C502

Low Cooker
C503

Washing Machine
C504

4 Drawers
C509

Fridge
C505

2 Welsh Dressers
C506



Sussex Kitchen

C537

For ages 2–5. This popular combination of home corner favourites provides many role play opportunities. A shop on High Street one day becomes a science laboratory the next, but there's always lots of work getting done. For older children, purchase two additional Drawers to raise Sink and Cooker height.



Kitchenette

C525

For ages 2–5. Cook a five star meal in a mini-kitchen. The two Drawer units in this compact kitchen make it adaptable for a wide range of children.



Toddler Collection

C530

For ages 1–3. Create a space your toddlers love exploring, with turning dials, shiny mirrors and posting holes. Pinch-free and sturdy, this child-friendly area is a worry-free world of discovery.



Starter Home Corner

C538

For ages 1–3. Starting with the basic items allows you to grow your collection in the future. (Studio flats are eco-friendly, and you're less likely to forget to turn off the stove burner!)

Drama Centre (C700)
and **Peg Tree (H559)**



The Peg Tree collects hats, scarves and necklaces.

Hook spots hold the Flowie in place.

Compact Dress-up Unit (C715)



Done for the day, or just ready for a change of scenery? Flip up the trim, roll to a new location, and flip it down to lock in place.



The dress-up box is a cosy space to climb into, and even the youngest toddlers can help at clean-up time.

Drama Centres

ECERS 24:5.4 ITERS 2:7.3, 5.3; 20:5.3

Role play, dramatic play, imaginative play – everyone agrees it's essential. It starts with a Dress-up Unit with lots of storage space. Click the arches into place, toss a Flowie over them, and you have an instant stage or cosy space. Made of transparent netting, the Flowie will give children a sense of being in their own world while you can still supervise.


The Compact Drama Centre saves on space and serves younger children. Instead of trays for storage, we provided a dress-up box.

Accessories

- Flowie, sage **C707**
218 cm x 310 cm
- Flowie, sky **C708**
218 cm x 310 cm
- Flowie, sand **C709**
218 cm x 310 cm



Drama Centre C700
Choose Flowie colour: ■ ■ ■
Includes Dress-up Unit, Arches Kit and Flowie



Dress-up Unit C705
Includes 3 clear Deep Trays and 3 clear Shallow Totes



Peg Tree H559



Drama Centre Arches Kit C706
Choose Flowie colour: ■ ■ ■
Includes 2 Arches and a Flowie




Compact Drama Centre C710
Choose Flowie colour: ■ ■ ■
Includes Compact Dress-up Unit, Compact Arches Kit, and Flowie



Compact Dress-up Unit C715



Theatre Set C945
Choose colour: ■ ■ ■
Includes Compact Drama Centre and Small Corner Stage Set



Compact Drama Centre Arches Kit C716
Choose Flowie colour: ■ ■ ■
Includes 2 Arches and a Flowie



See p.129

Stage Sets

Child's Rocker (J940)
The home corner can be busy, so give your children a place to relax.



Doll Cradle (C140)
The cradle can comfortably hold a small child with a soft toy.



Doll Bed (C110)
Stack up two to make a cosy bunk for sleepy dolls.

Pushcart (D120)



Carefully designed to resist tipping, the Pushcart is perfect for one-year-olds taking their first steps.



Doll Furniture

ECERS 24:5.3 ITERS 20:7.2, 5.4

Doll furniture supports children's love of dramatic and social play. This open-ended equipment is solidly constructed and provides rich opportunities to re-enact the events of daily life.

For ages 2–6



Home Corner Set C138
Includes Pushcart, Rocker, Doll High Chair and Bed




Playsize Set of Three C145
Includes Rocker, Cradle and Doll High Chair



Pushcart D120



Doll Cradle C140



Doll Bed C110



Child's Rocker J940



Doll High Chair D130



Children can easily lift and carry the Doll High Chair, using the side handholds.

